

OWNER'S MANUAL

8 CH DSP, 4 CH AMPLIFIER

RS-X8DSP4



Since 1985
TURKISH ENGINEERING

Precautions

Warning: To prevent unit be short circuit, please do not put it in the wet or damping places.

If unit catch water and any liquid that please turn off power immediately and do not open cover by yourself. Please contact with professional engineer for checking to avoid accident happen.



Packing List

For every package including below items, Please noticed retailer and Factory if shortage:


RS-X8DSP4 unit	1PC
User Manual	1PC
Head Unit Cable	1PC
USB computer tuning cable	1PC

Contents

Mobile Application Instructions.....	1-4
1. Features	
1.1 Audio specification、main audio signal process diagram.....	5
1.2 Input and output side panel.....	6
1.3 Software Introduction.....	6
1.4 Function Introduction.....	7
2. Installation	
2.1 System classic connecting reference.....	8
2.2 Unit connection.....	9
2.3 Low level RCA input/output.....	9
2.4 USB2.0 Port.....	10
3. Software Operation	
3.1 Software Installation.....	11
3.2 Run and turn off.....	11
3.3 Software interface.....	12
3.3.1 Input signal select.....	12
3.3.2 Output switch.....	13
3.3.3 Output voice, delay, type, mute and phase setting.....	13
3.3.4 Output signal equalizer and crossover operation.....	15
3.3.5 Output signal function operation.....	17
3.4 Setting introduce.....	18
3.4.1 Original setting change.....	19
3.4.2 Load and save to store a scene files on your computer....	21
3.4.3 Load and save the whole store a scene.....	22
3.5 Operations Introduction.....	23
3.5.1 Firmware update setting	23
3.5.2 Noise gate Setting.....	23
3.5.3 Source Volume Setting.....	24
3.5.4 Boot Default Source Selection.....	24
3.5.5 Information about the inquiry.....	24
3.5.6 Encrypt setting.....	24
4. Common trouble shouting.....	25

Mobile Application Instructions

Android mobile scan Qrcode on gift box to download the application to install RS-X8DSP4 app. Turn on the unit and plug in external bluetooth, then the external bluetooth will be power on and auto enter into a paring mode with blue light flash alternately. Open the bluetooth of your android mobile, searching DSP to pairing it to finish the connected.



1.User Operation Instruction

Main Interface



Main volume adjustment

● The main volume can be adjusted by pressing the main volume scale clockwise or counterclockwise by hand.



Input Source


1、Click Hi.Level button to switch input source.



E.g : Head unit input source is high level, then the Input source on app choice Hi.Level ◦

Preset

There are 1~6 presets to choose from.



Connection Status

1、【Red icon】 Red means not connected; 【Gray icon】 gray means connected.

When the mobile phone is connected to Bluetooth, open the mobile phone software and it will be connected automatically. The Bluetooth symbol turns green. The software can control the host playback and data adjustment.



2、click the mobile phone to Exit.
3、Click to enter the main interface. The main menu is at the bottom of the interface.



4、Slide [Volume bar] to adjust the main / subwoofer volume. The main volume is 0-66

Click 【EQ】 to enter EQ interface



Setting EQ Output channel

1、EQ curve(gain, Q value and frequency)



2、Output EQ gain setting: A total of 31 EQ, left and right sliding screen can select EQ, you can drag the slider up and down. PEQ mode (the equalizer frequency,Q value and gain are restored to their initial values).



3、Click each channel Freq in the pop-up dialog box to adjust the adjustment range: -20dB~-20dB.



Equalization settings

1、Click 【 Reset EQ 】 to restore the parameters of the 31-band equalizer to the original.
pass-through mode (the equalizer frequency, Q value and gain are restored to their initial values).




Channel settings

- 1.Choose from 8 channels to choose from
- 2.Output channel volume setting,Click  the speaker button to mute.



- 2、Click  to adjust the volume by sliding left and right.



- 2.Click phase for every output channel:
In Phase or Out Phase (0 °/180 °)



Crossover settings

Default Value : [MS], can switch to [CM] or [INCH]




- 1. Channel high-low-pass crossover setting with high-low-pass independent filtering.
- 2. Frequency Range: 20Hz~20KHz. Slope selection: 6 dB/Oct 、 12dB/Oct 、 24dB/Oct 、 30dB/Oct 、 36dB/Oct 、 42dB/Oct 、 48dB/Oct 、 OFF.



Output Signal Function

- Click [Link] to synchronize the data.



Delay setting

Click[Delay] to enter the delay interface,Then click  to enter the delay setting,Slide the corresponding direction of the dot to the left and right to set the delay. for the CH1 to CH8 speakers.



Player settings

Click [Player] to enter system interface, It can Perform to select lossless music playback/ pause/previous/next song



Mixer settings

Click [Output] to enter Mixer interface, It can USB-L, USB-R, digital left and digital right,Bluetooth left and Bluetooth right mix selection and adjustment.



Main menu settings

Click [Menu] Enter the menu at the upper left corner, It can Perform for Boot Source/Noise gate/ Encryption/Input Source volume /about /Restoration of factory setting/ exit setting.




Password:123456

1. Feature

1.1 Audio specification, main audio signal process diagram

This equipment adopts the audio extraction method with high sampling rate of 48KHz. The core processor is the digital signal processor (DSP) with high resolution 64 bit double precision floating point and 170 section 31 parametric equalizer or graphic equalizer, delay and frequency device (low shear and high cut filter, the types of specialized division include: Ning g / Bessel / Butterworth, CH1-CH8 nine slope 6dB and 12dB /18dB/ 24dB/30dB /36dB/ 42dB/ 48dB/off optional) etc.

Main audio signal process diagram



1. Feature

1.2 Input and output side panel




Figure 1.2.1

- | | |
|-------------------------------|--------------------------|
| 1.) Head unit connecting port | 2.) HOST / ACC Converter |
| 3.) Power LED | 4.) Low level RCA input |
| 5.) Low level RCA output | 6.) PC Connecting port |
| 7.) Optical input | 8.) Disk Connecting port |
| 9.) Remote Control | |

1.3 Software Introduction

RS-X8DSP4 PC software control: (please check 3. Software Operation detail)

- 1) Autotmetically detect whatever the hardware is connecting with USB cable, if ready and will connect with head unit autometically.
- 2) Display resolution over than 1280*760, or else cannot show fully.
- 3) Only for windows system's computers.

1. Feature

1.4 Function Introduction

Specification	
Active Range	≥110dB
S/N Ratio	≥100dB
T.H.D.	≤0.05%
Freq. Response	20Hz ~ 20KHz
Input Impedance	Low level input:20KΩ, High level input:240Ω
Low level output impedance	100Ω
Power Output (4Ω)	RMS 35W X4, Peak Power 60W X4
Signal input/output range	RCA Input: 6Vpp; High level: 26Vpp; RCA Output: 9Vpp; Amplifier: 26Vpp
Temperature	-20 ~ 70℃
Supply Voltage	DC 11V ~ 15V
Sampling rate	48KHz/24Bit
Turn-on REM output	+12 V starting voltage output(0.2A)
Power consumption	≤0.1W

Function	
Input signal type	Choice: 4 ch high level, 2 ch stereo AUX, Bluetooth, player, Optical
RCA output location	Freely definable output sound position and speaker type
Output signal gain	Gain range: Mute, 0dB to 60dB
Output signal equalizer	1-8 Each output channel 31 band equalizer engine: 1、 Equalizer type:1st equalizer for Q and low pass option. 2nd equalizer for Q and high pass option others for Q balance 2、 Frequency range: 20Hz ~ 20KHz, resolution 1Hz. 3、 Q (slope or gradient): 0.404 ~ 128 4、 Gain: -20.0dB ~ +20.0dB, resolution 0.1dB
Output signal crossover	Each output with 2 rank's high/low pass independant filter1 1. Professional filter type: Butterworth, Linkwitz-Riley, Bessel 2. Filter crossover: 20Hz - 20KHz , Resolution 1Hz 3. Filter slope setting: 6/12/18/24/30/36/42/48dB/Off/Oct.
Output phase and time delay	Each output channel can be adjusted for phase and time delay, parameter range Phase: 0 °/180 ° Time delay: 0.000-20.00ms, 0.00-692.0cm, 0.00-272 inch
Scene operations	Unit can keep 6-style of music scenes by preset.

2. System connections

2.1 System classic connecting reference




Figure 2.1

this connecting method is for two units input, please refer below:

1. Please use Plug & Play cable to connect original car unit and RS-X8DSP4 for upgrade audio system effects. Please use OUT7 and OUT8 RCA output when Install bass amplifier or subwoofer
2. with the player, using RCA low level input connection, mobile phone use standard AUX special line.

2. System connections

2.2 Unit connection




Figure 2.2

indication "1" is the plug connecting position and assort with connecting cable which is matching unit.(figure 2.2) Connecting wire specifically defined in the following table:

CH4+ OUT	CH4- OUT	CH3+ OUT	CH3- OUT	CH2 -	CH1 -	CH3 -	CH4 -	GND	+12V
CH1+ OUT	CH1- OUT	CH2+ OUT	CH2- OUT	CH2 +	CH1 +	CH3 +	CH4 +	REM OUT	REM IN

Direction:

1. only for the original Plug & Play cables, or user using others directly.
2. REM input, when the toggle switch to ACC, only ACC input; When the toggle switch is switched to DC, the two high level input lines of FL+/FL- are defined. When there is original car or other high level input, the machine will detect the audio signal to start the machine.

Note: when do not use high level input (only RCA low level input), the toggle switch dial in DC, defined in FL+/FR+/RR+/RL+ arbitrary a all can access REM or ACC input, can be normal to start the machine.

2.3 Low level RCA input/output indication

"4" "5" position where is "low level RCA input/output" (figure1.2.1)

1. Low level RCA inputs, usually followed by an external player RCA output as the auxiliary input, maximum input level is10VPP.
2. the low level RCA output, CH1 to CH4 signal with the original car interface is the same, but there is without power amplifier, the default output type of CH7 and CH8 is null, while the default output type of CH5 and CH6 is ultra-low left and ultra-low right, usually external bass amplifier, as bass strengthened. Of course, users can configure their own initiative RCA low level output to complete more high-end divided by two or three-way system.

2. System connections

2.4 USB2.0 Port

As shown in figure 1.2.1, the "6" indicator bit is the "USB2.0" position.




Figure 2.3

Use Random accessories USB cable into this hole on a computer connected to the PC, open tuning software to debug the sound system.

3. Software Operation

3.1 Software Installation

PC tuning software is no need to install drive program, plug and play.

Operating environment: Suitable for Windows XP / Vista / WIN7 / WIN8 operating system.

The installation procedure describes:

After you install the software and downloading, double-click the installation file, step down can be achieved by tuning the software is installed.

3.2 Turn on and turn off

Double-click the RS-X8DSP4 icon to open the software, and the main interface before online is shown in figure 3.2.1 :(the upper right corner refers to the unconnected state)



RS-X8DSP4 provides only wired USB PC software connection. Wired USB connection:

Ensure that RS-X8DSP4 power state, with a USB cable to connect to a computer through the USB interface, the computer will find the new device and automatically install the update equipment, after a few seconds the installation is complete. Mixer software will automatically line up with the hardware. Right corner refers to "connected" state.

3. Software Operation

3.3 Software interface



Figure 3.2.2

Software interface RS-X8DSP4 unit divided into the following functional:

1. as shown in figure 3.2.2, "1", input signal selection: high level, Bluetooth, RCA, player, Optical.
2. as shown in figure 3.2.2 "2", shows the main menu and connection status.
3. as shown in figure 3.2.2 "3", the high-pass and low-pass Settings of the divider.
4. as shown in figure 3.2.2, "4", area is output channel EQ setting.
5. as shown in figure 3.2.2, "5", shows the setting of delay space.
6. as shown in figure 3.2.2, "6", output channel configuration and common parameter adjustment area.
7. as shown in figure 3.2.2, "7", shows the setting of Mixer space.

3.3.1 Input signal select

In the online mode, in Figure 3.2.2 "1", click the appropriate input source, you can switch the audio input signal.

8. Optional: High level, Bluetooth, AUX, Player, Optical. The default audio source can be selected in the option of "2" zone. The default power source is high level. Users can choose AUX and player as the default power source.

The volume can be directly pushed left and right, or input volume value, scroll the mouse wheel, etc. Adjustable range: 0~60dB.

3. Software Operation

3.3.2 Output channel switch and operations

"6" area, click on the corresponding channel number in Figure 3.2.2 (CH1, CH2 CH8), you can switch to the corresponding channel to adjust relevant parameters when changing the channel editing, where there are only 3.2. 2 "4" zone (crossover and equalization parameters) will vary depending on the channel and change the parameter values.

3.3.3 Output volume, delay, type, mute and phase setting

In Figure 3.3.1, there are six output channels commonly used parameters are displayed, the user can quickly adjust the parameters directly here. Of course, users can also customize the horn type of each output channel. Specifically adjusted as follows:



Figure 3.3.1

1. the output volume control, volume control for each channel independently and the master volume, pushing the volume fader below each channel label can be in OFF (off), - adjust between 0dB to 60dB; while on the right also has a total volume of all output is adjustable, adjustment range is OFF (off), - between -39dB to 0dB.
2. mute and phase adjustment, also under the label of each channel are phase and mute both buttons select, and click on the button you can be between "positive phase" and "inverted" Switch, click the mute button You can switch between "open tone" and "off the sound." Figure 3.3.2 as follows:



Figure 3.3.2

3. Select delay units, which are in milliseconds, centimetres, and inches. The range of milliseconds: 0.000~20; Range of mm: 0~692;Range of inches: 0 to 272;

RS-X8DSP4 processor output signal path can be any type of configuration freedom to any sound field point and the speaker type. The system defaults to 4.1 full-range

3. Software Operation

passive mode. Figure 3.3.3 as follows ;



Figure 3.3.3

CH1: front left output

CH2: front right output

CH3: After a left-field output

CH4: right after the sound field output

CH7: left subwoofer output

CH8: Right subwoofer output

Users can be customize the speaker type for each output channel, the specific methods of operation:

The first step: Click on the right side of the "Reset Output Configuration" button in the dialog box, select the "Clear" button, return to the main interface, all channels are reset to "empty" (no connection to any speaker , there is no output of), as shown below 3.3.4:



Figure 3.3.4

The second step,

1. the output delay adjustment, is set in the delay space area to the left of the illustrated adjustment, as follows (Figure 3.3.5), click on the value of the input box next to the corresponding speaker can be entered after the delay value

3. Software Operation

corresponding units.



Figure 3.3.5

3.3.4 Output signal equalizer and crossover operation

Output channel equalizer and crossover editor mainly in the following areas of regulation, as shown in 3.3.6:




Figure 3.3.6

Gain, drag around to adjust the equalizer frequency points; when the mouse is moved to the left and right of the small red box, press and drag left and right to adjust the equalizer Q. All parameters are displayed simultaneously adjust the current real-time equalizer is also updated value EQ parameters editing area.

- 1. the output channel EQ editing method, all 31 band equalizer will work for the next parametric equalizer. When the parametric equalizer curve, if available in the box

3. Software Operation

below the corresponding input parameter values can be (frequency, Q value, and gain) adjusted in real time will also be revealed at the top (as shown in Figure 3.3.7 parametric equalizer case).



Figure 3.3.7

Straight balanced: the button shown in Figure 3.3.4, the current channel as long as there is an equalizer in the open state, this button will appear highlighted in green state, indicating that you can click this button to make all the equalizer current channel change to not start moving (directly). Click the button that will return to "restore the balance." Then click on "restore the balance" button will allow all current equalizer channel back to the last activated state.

Note: This operation will change the equalizer gain.

Reset balanced: the button shown in Figure 3.3.4, click this button to make all current channel equalizer parameters return to the initial state: uniform distribution of frequency, Q value is 1.2, a gain of 0dB.

2. the output channel divider editing method

In the column of "frequency divider" in figure 3.3.8, the parameter value of the device frequency divider. Type setting: drop-down menu to select the way, there are (Linkwitz-Riley), (Bessel) and (Butterworth) and other three options.

Frequency setting: via direct input value, scroll the mouse wheel up and down keys on the keyboard and other ways to adjust low-cut or high-cut frequency. Adjustment range: 20Hz ~ 20KHz.



Figure 3.3.8

Software Operation

Slope(slope)settings:6dB/Oct,12dB/Oct,18dB/Oct,24dB/Oct,30dB/Oct,36dB/42dB/Oct,48dB/Off/Oct and other 9 options.

Note: In 6dB / Oct, there is no type of algorithm, but a common type (displayed as NULL).

3.3.5 Output signal equalizer and crossover operation



figure 3.3.10

Reset EQ button:

It is used to restore the parameters of the 31-band equalizer to the original pass-through mode (the frequency of the equalizer, the Q value and the gain are restored to the initial value).

Restore All Equalizations button:

Switch between the currently designed equalizer state parameters and the pass-through mode (the gain of all equalization points is restored to 0 dB, the frequency and value are unchanged).

Lock output Configure button:

Click this button to configure the channels CH1 to CH8 to lock or unlock operation, it indicates that the configuration channel is locked, click this button again to unlock the display when the button is green. In the unlocked state, click CH1~ CH8 can be configured to output the positioning of the sound field; in the locked state, if the output channel sound field is empty, you can not click to enter the editing interface, only the output channel sound field is not empty, click on the channel to enter edit mode, but the channel is not possible to select the sound field.

Link output Configure button:

Click this button, a pop-up dialog box, select the synchronous mode (option to "copy from left to right" or "Copy from right to left" radio button), press "OK" to confirm; when you click this button again FBI releasing left and right channels function. (Note: the left or right channel by the FBI, the software will automatically lock output

3. Software Operation

channels, output of the equalizer, divider and output volume data may FBI mute, channels, output of the equalizer, divider and output volume data may FBI mute, phase, space and delay are not the FBI.) in the locked FBI, the item associated tone has an FBI logo be displayed.

Mixer settings: click "mixer" in the "7" area in Figure 3.2.2, then you can switch to (Figure 3.3.14) the relevant parameter settings for the corresponding adjustment.




figure 3.3.14

3.4 Setting introduce



Figure 3.4.1

As shown in Figure 3.4.1 RS-X8DSP4 software of the scene in three major types of actions: the machine stored scene data, computer data stored scene and the whole scene data manipulation.

1. the machine data stored scene operation: refers to the scene data is now running the machine and set aside six in one scene between the data stored load, save operations. (Note: the choice of input signal sources, the output signal and the output channel type configuration for the machine stored total volume not save scene data load operation).

3. Software Operation

2. the computer stored scene data operation: the machine is now running in the scene data is saved as a computer file, or to load a previously saved scene computer files to the machine running.

(Note: the choice of input signal sources, the output signal and the output channel type configuration for the computer stored a total volume not save scene data load operation).

3. the whole scene data: is to copy all the data in the machine to machine, or save all of the data on existing machines as computer files, of course, including all of the input and output configuration data and advanced options data. This is mainly used for data storage and copy machine.

3.4.1 Original setting change

1.save for the machine preset

This function is to save existing work scene preset scene for the machine data (total of 6).

Step1: Click on the main interface to the top menu " File" button will pop up all the scenes action item (see Figure 3.4.1).

Step2: Click "Save" item will pop up after the Save As dialog window machine preset (Figure 3.4.2).



Figure 3.4.2

Step 3: Figure 3.4.2 dialog box, does not show the name of the data indicates that this scene is the factory default data, select the user preset number you want to save the machine location (such as Option 4), and then point below the "save "button, you pop up as shown in Figure 3.4.3," enter the scene name "box. **If you select the number of the existing scene name, it will overwrite the original data! !**

3. Software Operation

Step 4: Enter a name (such as 4-abc), named in the point you want as shown in "Input Scene name" dialog box shown in 3.4.3 "OK" button to save and return as shown in Point "Exit" button to complete the save as preset scene machine operation. This completes the scene to save the current operating mode of the machine to the machine presets Group 6, and is also the current machine running scene, you can see the upper left corner of the software will display the current run of the name of the preset scene.




Figure 3.4.3

2.loading machine preset scenarios

This feature is to preset scene previously saved machine data (saved as a machine preset) out of tune as the machine is currently running scene.

- step1:** Click on the main interface to the top menu " File " button will pop up all the scenes action item (see Figure 3.4.1).
- Step2:** Click "Load" item will pop up after loading machine preset scene window dialog box (Figure 3.4.4).



Figure 3.4.4

3. Software Operation

Step3: as dialog box of figure 3.4.4 , select the machine where the user wants to load a preset number (as selected on the 3rd), and then point below the "import" button on the pop-up shown 3.4.5 loading data transfer progress shown in the wait window.




Figure 3.4.5

3.4.2 Load and Save to store scene files on your computer

1.save as a scene file on the computer

This function is to save the current machine working scene data to a computer in order to prepare the late call.

step 1: Click on the main interface to the top menu " File " button will pop up all the scenes action item (see Figure 3.4.1).

Step 2: Click "single File " will bring up the file after item Save As dialog window (Figure 3.4.6).




Figure 3.4.6

step 3: Enter the file name in the pop-up window you want, save point on it.

2.loading scene files on your computer

This function is previously stored in the scene file on the computer the machine work load for the current scene

step1: Click on the main interface to the top menu "File" button will pop up all the scenes action item (see Figure 3.4.1)

3. Software Operation

Step2: Click "computer import" after entry window will pop open file dialog box (Figure 3.4.7).




Figure 3.4.7

step 3: open the pop-up window, select the file name of the user you want to call, point to open it.

3.4.3 Load and save the whole store a scene

1, save the whole store the scene

This function is to save all the data on the machine is now on-line for a computer file data (data file of the whole machine, including the current job scenario, six groups of all machine data preset scene, output channel configuration data and advanced data and other options), to when copying machine call late the whole device. This action does not change any data now on-line machine Specific methods of operation and the "Save the scene file on the computer is" basically the same, please refer to the operation on their own.

2, load the whole scene

This function is to load previously saved on the computer the whole machine to machine data files (data file of the whole machine, including the current job scenario, six groups of preset machine all the scenes, the output channel configuration data scenario, six groups of preset machine all the scenes, the output channel configuration data and advanced data and other options data). That is, the previous overall good debugging machine data copied to now coupled machines.

We recommend similar models when making audio system, for the whole replication functions.

The specific operation method is basically the same as "loading the scene file on the computer", please refer to the operation by yourself.

3. Software Operation

3.5 Options Introduction

Noise/Source Volume/Boot default source/About.After click on the main interface to the top menu "Setup" button in Figure 3.5. it will pop up "Setup" of each menuitem, You can choose : Firmware update /




Figure 3.5

3.5.1 Firmware Update Setting

In the options menu, click the " Firmware Update" option with the mouse, and a message dialog box will pop up, in which you can set the password for encryption. shown in Figure 3.5.1.



Figure 3.5.1

3.5.2 Advanced Setting

In the options menu, click the " advanced " option with the mouse, you will can set the auxliary sound source/main SRC attenuation ratio/Noise gate start threshold/high fidelity ,shown in Figure 3.5.2



Figure 3.5.2

3. Software Operation

3.5.3 Source Volume Setting

In the options menu, click the "Source Volume" option with the mouse, and a message dialog box will pop up, in which you can set the volume for Hi-Level/Low Level/Bluetooth/player/Optical, shown in Figure 3.5.3



Figure 3.5.3

3.5.4 Boot default Source Setting

Click on the main interface to the top menu " Boot default Source" button will pop up the noise settings item (see figure 3.5. 6).



Figure 3.5. 6

3.5.5 Information about the inquiry

In the Options menu, use the mouse to click on the "About" option the system will pop up a message Query dialog box, in which you can query to: SEQ ID letter version information of the device, the software version information and device information.

3.5.6 Encryption Setting

In the options menu, click the "Encryption" option with the mouse, and a message dialog box will pop up, in which you can set the password for encryption. shown in Figure 3.5.6. Password:123456





Figure 3.5.6

4. Common troubleshooting

Before applying power, carefully check the cable is normal, we must ensure that all interfaces as a normal connection. Common Fault diagnosis and treatment



Troubleshooting methods:

No.	Symptom	Reason and solutions
1	No electricity	1. pls check if power linking correct? 2. pls check if REM IN if linking correct?
2	No voice	1. pls check if turn on mute style 2. pls check if input channel is correct?
3	cannot link USB	1. pls check if USB cable is setting correct 2. pls cekck if find name as " HID-compiling device" in the computer



**FOR MORE INFORMATION
PLEASE VISIT**

Join Our Community



www.reissaudio.com.tr